




Operating Instructions

WARNING

To prevent fire or shock hazard, do not expose the projection TV to rain or moisture.





This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

CAUTION

To prevent electric shock, do not use this polarized AC plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

CAUTION

When using TV games, computers, and similar products with your projection TV, or viewing a TV station whose logo always stays on the screen, keep the brightness and picture functions at low settings. If a fixed (non-moving) pattern such as a station logo is left on the screen for long periods of time, especially at a high brightness or picture setting, the image can be permanently imprinted onto the screen. These types of imprints are not covered by your warranty.

Note on Caption Vision

This television receiver provides display of television closed captioning in accordance with §15.119 of the FCC rules.

Note on convergence adjustment

Before you use your projection TV, make sure to adjust convergence. For details, see "Adjusting the Convergence Automatically – FLASH FOCUSTM –" on page 33.

Note to CATV system installer

This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Use of this television receiver for other than private viewing of programs broadcast on UHF, VHF, transmitted by cable companies or satellite for the use of the general public may require authorization from the broadcaster/cable company and/or program owner.

NOTIFICATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your warranty and your authority to operate this equipment.

CAUTION

How to reduce the risk of "Image Retention" on your Projection TV

Bright, stationary images such as TV station logos displayed on your TV can cause permanent damage to your TV, resulting in retention of the image in the picture.

Please take the following steps to reduce the risk of causing image retention:

View a variety of program sources or programming material.

Image retention can occur when bright stationary images such as TV station logos are viewed. Changing the program material viewed reduces the possibility that a single image will become imprinted on the picture tubes in your TV.

When viewing programs with stationary images, adjust the picture setting to reduce the "Picture" and "Brightness" levels. Image retention is accelerated by higher "Brightness" and higher "Picture" settings.

Please refer to your instruction manual for instructions on adjusting picture settings.

This will help you reduce the risk of causing image retention.

IMAGE RETENTION IS NOT COVERED BY YOUR WARRANTY

This document is for the remote control RM-Y909. MODELS: KP-46WT510, KP-51WS510, KP-57WS510, and KP-65WS510.

Please keep this notice with the instruction manual.

Safety

- Operate the projection TV only on 120 V AC.
- The plug is designed, for safety purposes, to fit into the wall outlet only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- ☐ If any liquid or solid object should fall inside the cabinet, unplug the projection TV immediately and have it checked by qualified service personnel before operating it further.
- ☐ If you will not be using the projection TV for several days, disconnect the power by pulling the plug itself. Never pull on the cord.

For details concerning safety precautions, see "IMPORTANT SAFEGUARDS" on page 4.

Installing

To prevent internal heat buildup, do not block the ventilation openings.

- Do not install the projection TV in a hot or humid place, or in a place subject to excessive dust or mechanical vibration.
- Avoid operating the projection TV at temperatures below 5°C (41°F).
- ☐ If the projection TV is transported directly from a cold to a warm location, or if the room temperature changes suddenly, the picture may be blurred or show poor color due to moisture condensation. In this case, please wait a few hours to let the moisture evaporate before turning on the projection TV.
- To obtain the best picture, do not expose the screen to direct illumination or direct sunlight. It is recommended to use spot lighting directed down from the ceiling or to cover the windows that face the screen with opaque drapery. It is desirable to install the projection TV in a room where the floor and walls are not of a reflective material.



As an ENERGY STAR® Partner, Sony Corporation has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

Trademark Information

TruSurround and the $(ullet)^{\textcircled{8}}$ symbol are trademarks of SRS Labs, Inc. TruSurround technology is incorporated under license from SRS Labs. Inc.

BBE and BBE Symbol are trademarks of BBE Sound, Inc. and are licensed by BBE Sound, Inc. under U.S. Patent No. 4,638,258 and 4,482,866.

Steady Sound, Digital Reality Creation, Caption Vision, CineMotion, Memory Stick, and Twin View are registered trademarks of Sony Corporation. ClearEdge VM and HD Detailer are trademarks of Sony Corporation.

Owner's Record

The model and serial numbers are located at the rear of the projection TV, below the Sony logo, on the sticker, and also on the TV box (white label). Record these numbers in the spaces provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No	
Serial No.	

IMPORTANT SAFEGUARDS

For your protection, please read these instructions completely, and keep this manual for future reference.

Carefully observe and comply with all warnings, cautions and instructions placed on the set or described in the operating instructions or service manual.

WARNING

To guard against injury, the following basic safety precautions should be observed in the installation, use and servicing of the set.

Use

Power Sources

This set should be operated only from the type of power source indicated on the serial/model plate. If you are not sure of the type of electrical power supplied to your home, consult your dealer or local power company. For those sets designed to operate from battery power, refer to the operating instructions.



This set is equipped with a polarized AC power cord plug (a plug having one blade wider than the other), or with a three-wire grounding type plug (a plug having a third pin for grounding). Follow the instructions below:

For the set with a polarized AC power cord plug

This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug still fails to fit, contact your electrician to have a suitable outlet installed. Do not defeat the safety purpose of the polarized plug by forcing it in.

For the set with a three-wire grounding type AC plug

This plug will only fit into a groundingtype power outlet. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to have a suitable outlet installed. Do not defeat the safety purpose of the grounding plug.

Overloading

fire hazard.

Do not overload wall outlets, extension cords or convenience receptacles beyond their capacity, since this can result in fire or electric shock.



Always turn the set off when it is not being used. When the set is left unattended and unused for long periods of time, unplug it from the wall outlet as a precaution against the possibility of an internal malfunction that could create a

If a snapping or popping sound from a TV set is continuous or frequent while the TV is operating, unplug the TV and consult your dealer or service technician. It is normal for some TV sets to make occasional snapping or popping sounds, particularly when being turned on or off.



Object and Liquid Entry

Never push objects of any kind into the set through the cabinet slots as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the set.



Attachments

Do not use attachments not recommended by the manufacturer, as they may cause hazards.



Cleaning

Clean the cabinet of the projection TV with a dry soft cloth. To remove dust from the screen, wipe it gently with a soft cloth. Stubborn stains may be removed with a cloth slightly dampened with solution of mild soap and warm water. Never use strong solvents such as thinner or benzine for cleaning.

If the picture becomes dark after using the projection TV for a long period of time, it may be necessary to clean the inside of the projection TV. Consult qualified service personnel.

Installation

Water and Moisture

Do not use power-line operated sets near water — for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc.



Accessories

Do not place the set on an unstable cart, stand, table or shelf. The set may fall, causing serious injury to a child or an adult and serious damage to the set. Use only a cart or stand recommended by Sony for the specific model of TV. No part of the TV set should overhang any edge of the TV cart or stand; any overhanging edge is a safety hazard. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.





Ventilation

The slots and openings in the cabinet and in the back or bottom are provided for necessary ventilation. To ensure reliable operation of the set, and to protect it from overheating, these slots and openings must never be blocked or covered.

Never cover the slots and openings with a cloth or other materials.



 Never block the slots and openings by placing the set on a bed, sofa, rug or other similar surface.



 Never place the set in a confined space, such as a bookcase or built-in cabinet, unless proper ventilation is provided.



Do not place the set near or over a radiator or heat register, or where it is exposed to direct sunlight.



Power-Cord Protection

Do not allow anything to rest on or roll over the power cord, and do not place the set where the power cord is subject to wear or abuse.



Antennas Outdoor Antenna Grounding


If an outdoor antenna is installed, follow the precautions below. An outdoor antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can come in contact with such power lines or circuits.

WHEN INSTALLING AN OUTDOOR ANTENNA SYSTEM, EXTREME CARE SHOULD BE TAKEN TO KEEP FROM CONTACTING SUCH POWER LINES OR CIRCUITS AS CONTACT WITH THEM IS ALMOST INVARIABLY FATAL.

Be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges.

Section 810 of the National Electrical Code (NEC) in USA and Section 54 of the Canadian Electrical Code in Canada provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

Antenna Grounding According to the National Electrical Code, ANSI/NFPA 70



Lightning

For added protection for this television receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna. This will prevent damage to the receiver due to lightning and power-line surges.

Service

Damage Requiring Service

Unplug the set from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power cord or plug is damaged or frayed.
- If liquid has been spilled into the set.
- If the set has been exposed to rain or water.
- ☐ If the set has been subject to excessive shock by being dropped, or the cabinet has been damaged.
- If the set does not operate normally when following the operating instructions.

 Adjust only those controls that are specified in the operating instructions.

 Improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the set to normal operation.
- When the set exhibits a distinct change in performance, it indicates a need for service.

Servicing

Do not attempt to service the set by yourself since opening the cabinet may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.



Replacement Parts

When replacement parts are required, be sure the service technician certifies in writing that he has used replacement parts specified by the manufacturer that have the same characteristics as the original parts.

Unauthorized substitutions may result in fire, electric shock or other hazards.

Safety Check

Upon completion of any service or repairs to the set, ask the service technician to perform routine safety checks (as specified by the manufacturer) to determine that the set is in safe operating condition, and to so certify. When the set reaches the end of its useful life, improper disposal could result in a picture tube implosion. Ask a qualified service technician to dispose of the set.



For Safety

Be careful when moving the projection TV

When you place the projection TV in position, be careful not to drop it on your foot or fingers.



Watch your footing while installing the projection TV.

Carry the projection TV in the specified manner

If you carry the projection TV in a manner other than the specified manner and without the specified number of persons, it may drop and a serious injury may be caused. Be sure to follow the instructions mentioned below.

- Carry the projection TV with the specified number of persons. (see page 11)
- Do not carry the projection TV holding the speaker grill.
- ☐ Hold the projection TV tightly when carrying it.
- Model KP-65WS510 has handles that you can use to carry the unit.

Contents

Introducing the Sony Projection TV Presenting the Sony Projection TV
Installing and Connecting the Projection TV
Contents
Inserting Batteries into the Remote Control10
Carrying Your Projection TV
Installing the Projection TV
Projection TV Controls and Connectors
Basic Connections (Connecting Cable TV or
Antenna)16
Connecting a VCR and Cable
Connecting a VCR and Cable Box20
Connecting Two VCRs for Tape Editing22
Connecting a Satellite Receiver
Connecting a Satellite Receiver with a VCR24
Connecting an Audio Receiver25
Connecting a DVD Player with Component
Video Connectors26
Connecting a DVD Player with A/V Connectors 27
Connecting a Digital TV Receiver28
Connecting a Camcorder29
Connecting an AV Receiver30
Using the CONTROL S Feature31
Setting Up the Projection TV Automatically32
Adjusting the Convergence Automatically
– FLASH FOCUS TM –33
Adjusting the Convergence Manually34
Using the Features
Using the Remote Control37
Watching the TV40
Watching the Digital TV42
Using Favorite Channels43
Using Twin View TM 44
Using the Freeze Function47
Using Scrolling Channel Index48
Using Wide Screen Mode50

Using the Menus

Overview	51
Using the Video Menu	52
Using the Audio Menu	54
Using the Channel Menu	
Using the Wide Menu	58
Using the Timer Menu	60
Using the Setup Menu	61
Other Information	
Programming the Remote Control	71
Operating Other Components with Your Pro	jection
TV Remote Control	74

Introducing the Sony Projection TV

Presenting the Sony Projection TV

Thank you for purchasing the Sony Projection TV. This manual is for models KP-46WT510, KP-51WS510, KP-57WS510, and KP-65WS510. KP-51WS510 is used for illustration purposes, unless indicated otherwise.

Features

Some of the features that you will enjoy with your new projection TV include:

- □ Hi Scan 1080[™]: Enables you to receive the 1080i, 720p, 480p and 480i digital TV formats. By using the VIDEO 5/6/7 IN jacks, you can connect a DTV (digital television) receiver to view DTV programs.
- DRCTM Multi-Function: Unlike conventional line doublers, the DRC feature doubles vertical and horizontal lines, resulting in four times the density for quality sources such as DVD, Satellite and Digital camcorder.
- CineMotion[™]: Reverse 3-2 pulldown processing provides optimal picture quality for film-based sources (media originally shot in 24 frames per second).
- Twin View[™]: Using Multi-Image Driver (MID-X), Twin View allows you to watch two programs side by side with the ability to zoom in on one picture and listen to the program in the selected window. You can watch pictures from two different sources (1080i, 720p, 480p or 480i) simultaneously.
- Steady Sound [™]: Equalizes volume levels so there is consistent output between programs and commercials.
- **Parental Control:** V-Chip technology allows parents to block unsuitable programming for younger viewers.
- Component Video Inputs: Offers the best video quality for DVD (480p, 480i) and Digital Set-top box (1080i, 720p, 480p, 480i) connections.
- **S-VIDEO Inputs:** Provides a high-quality image for connected equipment.
- **Favorite Channel Preview:** Preview up to eight favorite channels without leaving the current channel.
- Scrolling Channel Index: Allows you to view and choose channels from scrolling pictures without leaving the current channel.

- **Wide Screen Mode:** Allows you to watch 4:3 normal broadcasts in wide screen mode (16:9 aspect ratio).
- Auto Wide: Allows you to select the wide screen mode automatically.
- **Flash Focus**[™]: Allows you to adjust convergence automatically.
- Manual Convergence: Allows you to manually adjust the convergence of specific areas of the screen.
- Digital Visual Interface (DVI): Can accommodate a copyprotected digital connection (HDCP*) to other devices (such as digital set-top boxes) that have compatible interfaces. The DVI-HDTV input terminal is compliant with the EIA-861 standard and is not intended for use with personal computers.

Using this manual

We recommend that you carefully review the contents of the following three sections in the order shown to ensure that you fully understand the operation of your new projection TV.

1 Installing and Connecting the Projection TV

This section guides you through your initial setup. It shows you how to install your projection TV, to connect your new components and to connect the antenna and cable.

2 Using the Features

This section shows you how to begin using your new projection TV. It also shows you how to use your remote control functions.

3 Using the menus

This section teaches you how to access on-screen menus and adjust your projection TV settings.

Instructions in this manual are written for the remote control. Similar controls are also found on the projection TV console.

^{*} High-bandwidth Digital Content Protection


Installing and Connecting the Projection TV


Contents

The box contains your new projection TV, a remote control and two AA batteries. No peripheral cables are included. If you intend to add additional equipment to your projection TV, please check the hookup instructions for your desired setup before you begin. You may need to purchase cables and/ or splitters to complete the hookup properly.

Inserting Batteries into the Remote Control

Insert two size AA (R6) batteries (supplied) by matching the + and – on the batteries to the diagram inside the battery compartment.






- Remove the batteries to avoid damage from possible battery leakage whenever you anticipate that the remote control will not be used for an extended period.
- Handle the remote control with care. Avoid dropping it, getting it wet, or placing it in direct sunlight, near a heater, or where the humidity is high.
- Your remote control can be programmed to operate most video equipment. (See "Programming the Remote Control" on page 71.)


Carrying Your Projection TV

Carrying the projection TV requires four (4) or more people.


The projection TV has been equipped with casters for easy movement on a hard surface. Please move your projection TV using the casters. (KP-51WS510, KP-57WS510, and KP-65WS510 only)



Installing the Projection TV



Recommended viewing area (Vertical)



Recommended viewing area (Horizontal)

Connector Types

You may find it necessary to use some of the following connector types during set up.

Coaxial cable

Standard TV cable and antenna cable

Plug Type



S Video cable

High quality video cable for enhanced picture quality



Audio/Video cable



Video - Yellow

Audio (Left) - White

Audio (Right) - Red

Some DVD Players are equipped with the following three video connectors:

Y - Green

 P_B (C_B , C_b or B-Y) - Blue

 P_R (C_R , C_r or R-Y) - Red

CONTROL S cable

CONTROL S connections are exclusive to Sony products and allow greater control of all Sony equipment.



DVI cable


DVI connection for a high-bandwidth copy-protected signal




Projection TV Controls and Connectors


Front Panel Menu Controls

The front panel menu controls allow access to the on-screen menus without the use of a remote control. Pressing MENU brings up the on-screen menus. The arrow buttons move the on-screen cursor in the menus and by pressing the Select button (-;-) selects the menu item.



Projection TV Rear and Front Panel Connectors





Connection	Description
1 DVI-HDTV VIDEO AUDIO R/L (VIDEO 7 IN)	Can accommodate a copy-protected digital connection (HDCP*) to other devices (such as digital set-top boxes) that have compatible interfaces. The DVI-HDTV input terminal is compliant with the EIA-861 standard, and is not intended for use with personal computers. See the instruction manual that came with your equipment for details about connecting and using it with the TV.
2 AUX	Allows you to view local and cable channels if your cable provider does not feature local channels. You can switch between local and cable channels easily by pressing ANT on the remote control. Devices connected to the AUX input cannot be viewed in Twin View.
3 TO CONVERTER	This is a VHF/UHF OUT jack that lets you set up your projection TV to switch between scrambled channels (through a cable box) and normal cable channels (CATV). Use this jack instead of a splitter to get better picture quality when switching between scrambled and unscrambled cable channels.
4 VHF/UHF	Connects to your VHF/UHF antenna or cable.
5 S VIDEO (Rear and front)	Connects to the S VIDEO OUT jack of your VCR or other S VIDEO-equipped video component. Provides better picture quality than the VHF/UHF jacks or the Video IN jack.
6 VIDEO (L/R)/AUDIO (Rear and front)	Connects to the audio and video OUT jacks on your VCR or other video component. A fourth video input (VIDEO 2) is located on the front panel of the projection TV.
7 Y/P _B /P _R (L/R)/AUDIO	Connects to your DVD player's or Digital Set-top box's component video (Y, PB, PR) and audio (L/R) jacks.
8 TV OUT	Outputs the signal that the TV is tuned to (regardless of the picture displayed on the screen).
9 AUDIO OUT (VAR/FIX) L (MONO)/R	Connects to the left and right audio inputs of your audio or video component.
10 CONTROL S IN/OUT	To control other Sony equipment with the projection TV's remote control, connect the CONTROL S IN jack of the equipment to the CONTROL S OUT jack on the projection TV with the CONTROL S cable. To control the projection TV with a remote control for another Sony product, connect the CONTROL S OUT jack of the equipment to the CONTROL S IN jack on the projection TV with the CONTROL S cable.

^{*} High-bandwidth Digital Content Protection.

Basic Connections (Connecting Cable TV or Antenna)

Connecting Directly to Cable or an Antenna

The connection you choose depends on the cable found in your home. Newer homes are equipped with standard coaxial cable (see A); older homes probably have 300-ohm twin lead cable (see B); other homes may contain both (see C).


A VHF Only or VHF/UHF or Cable



B VHF Only or UHF Only or VHF/UHF




C VHF and UHF



Cable and Antenna

If your cable provider does not feature local channels, you may find this setup convenient.



Select CABLE or antenna (ANT) mode by pressing ANT on the remote control.

To receive channels with an antenna, you need to turn your Cable to Off (see page 56) and perform the Auto Program function (see page 57).

Cable Box Connections


Cable Box and Cable

This is the preferred basic cable TV hookup to use if:

- Your cable TV company scrambles some channels, but not all of them (pay channels vs. regular cable channels) and you need to use a cable box, and
- ☐ You want to enjoy the Twin View feature.

With this setup you can:

- Use the projection TV remote control to change channels using your cable box when the signal is scrambled.
- ☐ Use the projection TV remote control to change channels using your projection TV when the signal is not scrambled. (Your projection TV's tuner provides a better signal than the cable box.)
- Use the Twin View feature. (When all channels are routed through your cable box, only one channel is sent to the projection TV, so you can not use the Twin View or Channel Index features for your cable box.)
- DIGITAL CABLE BOX USERS: Do not use this connection. The TO CONVERTER jack is not compatible with digital cable boxes.
- Connect the Cable TV cable to the projection TV's VHF/UHF jack.
- 2 Using a coaxial cable, connect the projection TV's TO CONVERTER jack to the cable box's IN jack. The projection TV's internal converter allows you to switch between unscrambled signals coming straight into the projection TV and scrambled signals coming in through the cable box, eliminating the need for an external splitter.
- 3 Using a coaxial cable, connect the cable box's OUT jack to the projection TV's AUX jack.



Pressing ANT on the remote control switches between the channels coming in through the cable box (scrambled) and those coming directly to the TV (unscrambled).

Installing and Connecting the Projection TV


Cable Box Only

Use this hookup if:

- You subscribe to a cable TV system that uses scrambled or encoded signals requiring a cable box to view all channels, and
- You do not intend to hook up any other audio or video equipment to your projection TV.

When all channels are routed through your cable box, only one unscrambled channel is sent to the projection TV, so you cannot use the Twin View feature. If some channels are scrambled, but others are not, consider using the hookup on page 17 instead.

- 1 Connect the coaxial connector from your cable service to the cable box's IN jack.
- 2 Using a coaxial cable, connect the cable box's OUT jack to the TV's VHF/UHF jack.



Also, set Cable to On in the Channel menu (see page 56).

- Your Sony remote control can be programmed to operate your cable box (see "Programming the Remote Control" on page 71).
- To change channels using the cable box, set your projection TV to channel 3 or 4 depending on the cable box channel output. If you will be controlling all channel selection through your cable box, consider using the Channel Fix feature to set your projection TV to channel 3 or 4 (see page 57).

If you have a digital cable box, you cannot use this connection because the TO CONVERTER jack is not compatible with digital cable boxes.

Setting the Channel Fix feature in the Channel menu (see "Using the Channel Menu" on page 56), ensures that you do not accidentally switch the channels using your projection TV.


Connecting a VCR and Cable

Use this hookup if:

☐ You have cable TV that does not require a cable box.

Disconnect all power sources before making any connections.

- Connect the cable TV cable to the VCR's IN jack.
- 2 Using a coaxial cable, connect the VCR's OUT jack to the projection TV's VHF/UHF jack.
- 3 Using AUDIO and S VIDEO cables, connect the VCR's Audio and S Video OUT jacks to the projection TV's AUDIO and S VIDEO IN jacks.



If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

Connecting a VCR and Cable Box

Use this hookup if:


- ☐ Your cable TV company scrambles some channels, but not all of them (pay channels vs. regular cable channels) and you need to use a cable box, and
- ☐ You want to enjoy the Twin View feature.

With this setup you can:

- ☐ Use the projection TV remote control to change channels on your cable box when the signal is scrambled. To program your Sony remote control to operate your cable box, see "Programming the Remote Control" on page 71.
- Use the projection TV remote control to change channels using your projection TV when the signal is not scrambled. Your projection TV's tuner provides a better signal than the cable box.
- Use the Twin View feature. (When all channels are routed through your cable box, only one signal is sent to the projection TV, so you cannot use the Twin View feature.)

Disconnect all power sources before making any connections.

- Connect the Cable TV cable to the projection TV's VHF/UHF jack.
- 2 Using a coaxial cable, connect the TV's TO CONVERTER jack to the cable box's IN jack. The projection TV's internal converter allows you to switch between unscrambled signals coming straight into the projection TV and scrambled signals coming in through the cable box, eliminating the need for an external splitter.
- DIGITAL CABLE BOX USERS: If you are connecting a digital cable box, you will need a special bi-directional splitter that is designed to work with your digital cable box. Contact your cable provider for details.
- 3 Using a coaxial cable, connect the cable box's OUT jack to the VCR's IN jack.
- 4 Using AUDIO and S VIDEO cables, connect the VCR's AUDIO and S VIDEO OUT jacks to the projection TV's AUDIO and S VIDEO IN jacks.
- 5 Using a coaxial cable, connect the VCR's OUT jack to the projection TV's AUX jack.
- To view scrambled channels, press ANT to switch to the AUX input. Change channels using your cable box.



Rear of projection TV


- If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.
- You will not be able to change channels on the VCR. Set your projection TV and VCR to channel 3 or 4, depending on your cable box.
- Pressing ANT on the remote control switches between the channels coming in through the cable box (scrambled) and those coming directly to the projection TV (unscrambled).
- If you are connecting a digital cable box, you will need a special bi-directional splitter designed to work with your cable box.

Connecting Two VCRs for Tape Editing

If you connect two VCRs, you can record from one VCR to the other while using your projection TV to monitor what is being recorded.

Disconnect all power sources before making any connections.

- Using AUDIO and VIDEO cables, connect the playback VCR's AUDIO and VIDEO OUT jacks to the recording VCR's Audio and Video IN jacks.
- 2 Using AUDIO and VIDEO cables, connect the recording VCR's AUDIO and Video OUT jacks to the projection TV's AUDIO and VIDEO IN jacks.



- To perform tape editing, set the projection TV to the video input intended for playback by pressing TV/VIDEO on the remote control.
- You may need to change the video input on your VCR. Consult your VCR's operating manual for instructions.
- If both VCRs have an S VIDEO jack, you can use the S VIDEO connection instead of the yellow video cable on a combined A/V cable.


 To use an S VIDEO cable, connect the VIDEO OUT jack of the playback VCR to the VIDEO IN jack of the recording VCR. Since S VIDEO does not provide audio, you must still connect audio cables to provide sound.
- You cannot record signals from equipment connected to the Y, PB, PR input.

Connecting a Satellite Receiver

Disconnect all power sources before making any connections.

- 1 Connect the satellite antenna cable to the satellite receiver's SATELLITE IN jack.
- 2 Using AUDIO and S VIDEO cables, connect the satellite receiver's AUDIO and S VIDEO OUT jacks to the projection TV's AUDIO and S VIDEO IN jacks.
- 3 Connect a coaxial cable from your cable or antenna to the projection TV's VHF/UHF jack.
- If your satellite receiver is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.


Rear of projection TV



Connecting a Satellite Receiver with a VCR

Disconnect all power sources before making any connections.

- Connect the satellite antenna cable to the satellite receiver's SATELLITE IN jack.
- 2 Connect the CATV cable to the VCR's VHF/UHF IN jack.
- 3 Using a coaxial cable, connect the VCR's OUT jack to the projection TV's VHF/UHF jack.
- 4 Using AUDIO and S VIDEO cables, connect the satellite receiver's AUDIO and S VIDEO OUT jacks to the VCR's AUDIO and S VIDEO IN jacks.
- 5 Using AUDIO and S VIDEO cables, connect the VCR's AUDIO and S VIDEO OUT jacks to the TV's AUDIO and S VIDEO IN jacks.




- Be sure your VCR's video input is set correctly. Consult your VCR's operating manual for instructions.
- ∠ Use TV/VIDEO to select
 - VIDEO 1 to watch satellite TV or the VCR (your VCR must be turned on).
 - VHF/UHF to watch cable TV.
- If your VCR or satellite receiver is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

Connecting an Audio Receiver

Disconnect all power sources before making any connections.

Using audio cables, connect the projection TV's AUDIO OUT (VAR/FIX) jacks to the audio receiver's audio LINE IN jacks.

Rear of projection TV




Connecting a DVD Player with Component Video Connectors

This is the preferred hookup to use if:

■ Your DVD player has component (Y, B-Y, R-Y) jacks.

Disconnect all power sources before making any connections.

- Using three separate component video cables, connect the DVD player's Y, B-Y and R-Y jacks to the Y, PB and PR jacks on the projection TV. Use the VIDEO IN 5 or 6 connections.
 - The Y, B-Y and R-Y jacks on your DVD player are sometimes labeled Y, CB and CR, or Y, PB and PR. If so, connect the cables to like colors.
- 2 Using an audio cable, connect the DVD player's Audio OUT jacks to the projection TV's AUDIO IN jacks. Be sure to use the same row of inputs that you used for the video connection (VIDEO IN 5 or 6).



Connecting a DVD Player with A/V Connectors

Use this hookup if:

- Your DVD player does not have component (Y, PB, PR) jacks.
- If your DVD player has video component output connectors: for best picture quality use the connection described on page 26.

Disconnect all power sources before making any connections.

- Using audio cables, connect the DVD player's Audio OUT jacks to the projection TV's AUDIO IN jacks.
- 2 Using an S VIDEO cable, connect the DVD player's S VIDEO jack to the projection TV's S VIDEO jack.

PREAR OF projection TV S VIDEO VIDE

- Use TV/VIDEO on the remote control to switch between the VCR, DVD player and cable TV inputs.
- If your VCR is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.

Connecting a Digital TV Receiver

- Be sure to read the Set-top box manual.
- Some Digital TV
 Receivers are equipped with a DVI connection.
 Refer to your Digital TV
 Receiver manual for setup instructions using this connection.

Disconnect all power sources before making any connections.

- 1 Using three separate component video cables, connect the Digital TV Set-top box's Y, PB and PR jacks to the projection TV.
 - The Y, PB and PR jacks do not provide audio, so audio cables must be connected to provide sound.
 - Component video connection is necessary to view 480p, 720p, and 1080i formats. You may also use the S VIDEO or Composite Video connections, however, component video (Y, PB, PR) will provide the best picture quality for all format types.
- Using an audio cable, connect the Digital TV Set-top box's Audio OUT jacks to the projection TV's AUDIO IN jacks.

Digital TV Set-top box

| Victor | Vict

RK-74A (not supplied)


- You cannot record the signal from any equipment connected into the Y. PB and PR connectors.
- This projection TV is not compatible with digital TV receivers configured with RGB or VGA output connectors.
- The DVI connection is compliant with the EIA-861 standard and is not intended for use with personal computers.

Connecting a Camcorder

For easy connection of the camcorder, the projection TV has front Audio and Video inputs (shown below). However, if you prefer, you can also connect the camcorder to the projection TV's rear Audio and Video IN jacks.

Using AUDIO and S VIDEO cables, connect the camcorder's Audio and S VIDEO OUT jacks to the projection TV's AUDIO and S VIDEO IN jacks.

- If you have a mono camcorder, connect its left audio output to the projection TV's AUDIO L (MONO) jack.
- If your camcorder is not equipped with S VIDEO, use a VIDEO cable (yellow) instead of the S VIDEO cable.



Connecting an AV Receiver


You can connect an AV receiver using both composite video and S VIDEO. If both are connected, then the TV will detect and display an S VIDEO signal. To take advantage of this feature, connect your receiver with Video 1.

For greater control of all audio and video equipment, connect an AV receiver.

Change "Video Label" for the VIDEO 1 input to "Receiver" (see page 62).


Disconnect all power sources before making any connections.

- Connect the coaxial cable from the incoming cable connection or antenna to IN on the VCR.
- 2 Using a coaxial cable, connect OUT on the VCR to VHF/UHF on the projection TV.
- 3 Using a VIDEO cable, connect VIDEO of VIDEO 1 IN on the projection TV to MONITOR OUT on the AV receiver.
- 4 Using an AUDIO/VIDEO cable, connect TV OUT on the projection TV to AUDIO/VIDEO 2 IN on the AV receiver.
- 5 Using an AUDIO/VIDEO cable, connect the video equipment to the AV receiver.
- Select the Setup menu and set "Video Label" to "Receiver" to fix your TV's input to AV receiver (see "Video Label" on page 62).



Using the CONTROL S Feature

CONTROL S allows you to control your projection TV system and other Sony equipment with one remote control. In addition to allowing you to control multiple devices with one remote control, the CONTROL S feature allows you to always point your remote control at your projection TV, instead of having to point it at the other equipment, which might be hidden or out of direct line of sight.



Setting Up the Projection TV Automatically


After you finish connecting your projection TV, you can run Auto Setup to set up your channels. The Auto Setup screen appears when you turn your projection TV on for the first time after installing it. If you do not want to set up the channels at this time, you can do it later by using the Auto Program feature in the Channel menu (see page 57).

The Auto Setup feature does not apply for installations that use a cable box for all channel selection.

Using Auto Setup

- 1 Press POWER on the front panel of your projection TV or on the remote control to turn on the projection TV.
- Press the TV (FUNCTION) button on your remote control. Red light will briefly appear.
- Press CH+ on your projection TV to run Auto Setup, or press CH- to exit. If you use the channel buttons on your remote control, be sure to use the main set of buttons $((\stackrel{ch}{+}))$.

Projection TV front panel



You can run Auto Program by selecting it in the Channel menu, as described on page 57.


Adjusting the Convergence Automatically – FLASH FOCUS™ –

The projection tube image appears on the screen in three colors (red, green and blue). If they do not converge, the color is poor and the picture blurs.

Before you use your projection TV, be sure to adjust the convergence.


The FLASH FOCUS feature allows you to adjust the convergence automatically.

It is recommended to perform FLASH FOCUS about 30 minutes after the projection TV is first turned on.



- 1 Receive a TV or cable TV program.
- 2 Press FLASH FOCUS.

The cross pattern shown below appears and FLASH FOCUS begins to work. The adjustment is completed when the cross pattern becomes white and you are returned to the program you were watching.




- You cannot perform any other functions until FLASH FOCUS has completed its cycle.
- If you perform any other operation while FLASH FOCUS is in progress, FLASH FOCUS operation is canceled.
- Unshielded speakers or other metallic objects can cause picture distortion if placed close to the projection TV.
- If you would like to manually perform additional fine adjustments, see page 34.

Adjusting the Convergence Manually

The Manual Convergence feature gives you more control over the TV's picture than the Flash Focus feature, allowing you to fine-tune the color alignment of each section of the TV screen.

- Before using Manual Convergence, you must first perform Flash Focus (as described on page 33).
- Let use the joystick of your remote control to perform the steps below.
- For details on using the Setup Menu, see page 61.
- Press MENU to display the Menu.
- Move the joystick ← or → to highlight the Setup icon and press 🕣.
- 3 Move the joystick to highlight Convergence and press ①.

A pattern of white crosses appears, with a yellow **[**] around one of the crosses. Aligned crosses (which do not need adjustment) look white and have little or no red or blue showing. Crosses that are not aligned show red or blue shades beyond their edges.



- You can scroll up and down through the 9 x 7 field of crosses to manually converge all portions of the screen.
- 4 Using the joystick, move the **[**] to surround a cross that you want to adjust. Press (+). The **[**] changes to red.
- 5 If the cross that you selected has red edges, move the joystick until the red image is replaced with a white cross. Once you have finished this (or the cross does not have red edges), press 💮. The 📘 T changes to blue.
- If the cross you selected has blue edges, move the joystick until the blue image is replaced with a white cross. Once you have finished this, press

 . The . changes to yellow again.
- Repeat steps 4 to 6 to adjust other crosses. When finished, press MENU to exit the manual convergence screen and the Setup menu.

Notes on Adjusting the Convergence Manually

- ☐ For best results, stand about 3 to 5 feet back from the picture when adjusting the convergence. Begin with the crosses in the center area of the screen and, once those are adjusted, move to the crosses on the edges of the screen.
- You can make separate adjustments to each wide mode: Full/Normal, Zoom, Wide Zoom, and 1080i high-definition input. The cross pattern settings appear different in each wide mode, but the adjustment procedure is the same. Press the WIDE MODE button on the remote to toggle through the wide mode screens.

Using the Features

Outside Panel

Button

Using the Remote Control

The following table describes the buttons on the remote control that are for more advanced functions.

Description

on page 52.


defaults.

Favorite Channels" on page 43.

11 FAVORITES

12 RESET

Button Descriptions




Button	Description
1 MUTING	Press to mute the sound. Press again or press VOL + to restore the sound.
2 SLEEP	Press repeatedly until the projection TV displays the time in minutes (15, 30, 45, 60, or 90) that you want the projection TV to remain on before shutting off automatically. Cancel by pressing until Sleep Off appears or turning the power off. While the Sleep feature is set, press once to view the remaining time.
3 ANT	Changes between the VHF/UHF input and the AUX input.
4 DISPLAY	Press once to display the current time and channel label (if set) and channel number. Press again to turn Display off. See page 60 for details on setting the time.
5 JUMP	Press to jump back and forth between two channels. The projection TV alternates between the current channel and the last channel that was selected.
6 FREEZE	Freezes the window picture. Press again to restore the picture.
7 INDEX	Press to enter the Scrolling Channel Index mode. You can view and select from all receivable channels scrolling on the screen without leaving the current one.
8	The joystick allows for movement of the on-screen cursor. Pressing down on the center of the joystick selects the item.
9 VOL +/-	Adjusts the volume.
10 PIC MODE	Press repeatedly to step through the available video picture modes: Vivid, Standard, Movie and Pro. Also available in

the Video menu. For details, see "Selecting Video Options"

Displays the Favorite Channels list. For details, see "Using


Press when in a menu to reset the settings to the factory

Using the Features



To scan rapidly through the channels, press and hold down CH+ or CH-.

Button	Description
13 POWER buttons (GREEN)	Turn on and off the projection TV and other audio/video equipment you have programmed into the remote control. For instructions, see "Programming the Remote Control" on page 71.
14 FUNCTION buttons	Select the equipment (TV, SAT/CABLE) that you want to operate. The indicator lights up momentarily when pushed to show which device the remote control is operating.
15 TV/VIDEO	Cycles through the video equipment connected to your projection TV's video inputs: TV, VIDEO 1, VIDEO 2, VIDEO 3, VIDEO 4, VIDEO 5, VIDEO 6 and VIDEO 7.
16 0 – 9 and ENTER	Press 0 - 9 to select a channel, the channel changes after 2 seconds. Press ENTER to select immediately.
17	Turns on/off Twin View. For details, see "Using Twin View TM " on page 44.
GUIDE	Displays the program guide of your satellite.
18 MENU	Press to display the projection TV on-screen menu. Press again to exit from the menu.
19 CH +/-	Scan through channels.
20 DRC/ CINEMOTION	Press repeatedly to step through the available high- resolution picture modes: Interlaced, Progressive and CineMotion. For details, see "Using the Video Menu" on page 52.
21 WIDE MODE	Press to step through the wide screen modes: Wide Zoom, Normal, Full and Zoom. For details, see "Using Wide Mode" on page 50.




Inside Panel	
Button	Description
1 SYSTEM OFF	Press to turn off the projection TV and all equipment
	connected with S-Link.
2 -	Play
3 ◀◀	Rewind
4 REC	Record
5 ■	Stop
6 DVD MENU	Displays the DVD menu.
7 MTS/SAP	Press to scroll through the Multi-channel TV Sound (MTS) options: Stereo, Auto SAP, and Mono.
8 CODE SET	Used for programming the remote control to operate non- Sony video equipment. For details, see "Programming the Remote Control" on page 71.
9 POWER	Press to turn on the DVD/VCR player you have programmed into the remote control. For instructions, see "Programming the Remote Control" on page 71.
10 >>	Fast-forward
AV2 -	Use to switch control for connected video equipment. You can program one video source for each switch position. For details, see "Programming the Remote Control" on page 71.
12	Pause (Press again to resume normal playback)
13 MENU	Displays the Video equipment menu.
14 ↑ , ↓ , ← , → , and ENTER	Use to operate the DVD menu.
15 🔊	Press to select an audio option: Steady Sound On or Off.

Watching the TV

Many TV features can be accessed directly through the remote control. The following will explain the function of some of the buttons found on your remote control.

Buttons for Projection TV Operations



1 TV (FUNCTION)

Activates the remote control for use with the projection TV.

2 ANT— (AUX input)

Press to change between the VHF/UHF input and the AUX input.

3 TV (POWER)

Turns the projection TV on and off. If a video input indication (e.g., VIDEO 1, VIDEO 2) appears on the screen, press TV/VIDEO or CH +/ – until a channel number appears.

4 0-9 and ENTER

Use for direct channel selection. Press 0-9 to select a channel (for example, to select channel 10, press 1 and 0). The channel will change after 2 seconds, or you can press ENTER for immediate selection.

5 CH +/-

Press to scan through the channels (+ up or – down).

6 VOL +/-

Press to adjust the volume (+ up or – down).

7 JUMP

Press to alternate or jump back and forth between two channels. The projection TV will jump between the current channel and the last channel selected.

8 MUTING

Press to mute the sound. "MUTING" will appear on the screen and will dim three seconds later. To restore the sound, press again or press VOL +.


9 FREEZE — (yellow labeled button)

This is useful when you need to copy down information that appears on the TV's screen (see "Using the Freeze Function" on page 47).

10 SLEEP

Press repeatedly until the projection TV displays the approximate time in minutes (15, 30, 45, 60, or 90) that you want the projection TV to remain on before shutting off automatically.

Cancel by pressing SLEEP until "Sleep Off" appears or turning the power off.



11 DISPLAY

Press to display the channel number, current time and channel label (if set).

To turn the display off, press DISPLAY again.

12 TV/VIDEO

Press repeatedly to scroll through available video inputs: TV, VIDEO 1, VIDEO 2, VIDEO 3, VIDEO 4, VIDEO 5 VIDEO 6, and VIDEO 7.

If you select Skip as a Video Label in the Setup menu, your projection TV will skip the video input you selected (see "Video Label" on page 62).

13 MTS/SAP

Press to scroll through the Multi-channel TV Sound (MTS) options (see "MTS" on page 54).

14 PIC MODE

Press PIC MODE repeatedly to directly choose one of four different video modes that best suits the program you are watching.

Vivid: Select for enhanced picture contrast and sharpness.

Standard: Select to display a standard picture for normal viewing environments.

Movie: Select to display a finely detailed picture for low light environments.

Pro (Professional): Select to display a picture with minimum enhancements.

When you select each mode, you can also adjust the picture quality (such as Brightness, Color, etc.) to suit your taste. For details, see "Mode" on page 52.

Watching the Digital TV

When you have connected the DTV receiver, you can enjoy digital TV programs. This projection TV is capable of receiving 1080i, 720p, 480p and 480i digital TV formats (note that 720p is displayed as 480p).

To view a digital TV program

- 1 Connect the DTV receiver to VIDEO 5, 6 or 7 IN on the projection TV. (for details, see page 28)
- Press TV/VIDEO to select VIDEO 5, 6 or 7.
- 3 Select a digital channel on the DTV receiver. For details, see the Operating Manual of the DTV receiver.
- 4 Adjust the volume of the projection TV as necessary.

Using Favorite Channels

The Favorite Channel feature lets you select programs from a list of favorite channels that you preset.

To display a list of your favorite channels:

- Your Favorite Channel options can be set automatically or manually. The factory setting for Favorite Channel is Auto.

 When Favorite Channel is set to Auto, the last eight channels selected with 0-9 buttons will be set as Favorite Channel options. If you want to input your own selections as Favorite Channel settings, see "Favorite Channel" on page 56.
- Press FAVORITES.

The Favorite Channel options appear.



2 Move the joystick up or down to highlight the channel you want to watch. The program of that channel appears in the preview window. Press (*) to select.

Using Twin View™

Twin View enables you to watch two programs at the same time. You can also change the size of both the left and right pictures.

Activating Twin Pictures

To display twin pictures

- Make sure your projection TV is tuned to a working channel.
- Press .





To cancel twin pictures

☐ Press ☐ again (or press ④).

Activating the Picture

Although two pictures appear on the screen at the same time, only one picture is active. For an active picture, you can:


- Change channels.
- ☐ Adjust the volume.
- Switch the input sources from VHF/UHF to cable by pressing ANT or TV/VIDEO to switch the video input.
 When the picture on the right is activated, the input sources cannot be

When the picture on the right is activated, the input sources cannot be switched to VIDEO 5, 6, 7, or AUX by pressing ANT.

☐ Change the picture size (see page 46).

To activate the right picture

■ Move the joystick to the right.



To activate the left picture

■ Move the joystick to the left.

- Factors Affecting Twin View:
 - If you use a cable box to view all channels, the same channel appears in both windows because the cable box unscrambles only one channel at a time.
 - If you use a cable box, you can view the cable box output in one window and view a different source (such as a VCR or DVD player) in the second window by using the TV/VIDEO button.
 - Sources connected to the AUX, VIDEO 5, VIDEO 6, and VIDEO 7 inputs display in the left window, but not the right.
 - If you are viewing a 4:3 source and a 16:9 enhanced source (such as a DVD) side by side, the 4:3 source appears larger.
 - Twin View does not display channels that are blocked by Parental settings (page 63).
- The active picture is highlighted in cyan.

Changing the Picture Size

The zoom feature lets you change the size of the left and right pictures.

To enlarge the left picture (reduce the right)

- Move the joystick left to activate the left picture (if not already activated).
- 2 Move the joystick up to enlarge the picture and move the joystick down to reduce the picture.











To enlarge the right picture (reduce the left)

- Move the joystick right to activate the right picture (if not already activated).
- Move the joystick up to enlarge the picture and move the joystick down to reduce the picture.

When you adjust the twin screen sizes, the projection TV memorizes the change. The next time you use the Twin View function, the memorized sizes appear.

Using the Freeze Function

The FREEZE button allows you to temporarily capture a program's picture. You can use this feature to write down information such as phone numbers, recipes, etc.

To use the Freeze function

- 1 When the program information you want to capture is displayed, press FREEZE.
- 2 The projection TV switches to Twin View mode and displays the "frozen" picture on the right, while the current program continues on the left.



3 To cancel and return to normal viewing, press FREEZE.

Freeze feature is not available if you are already in Twin View™ or Index mode.

Using Scrolling Channel Index


Scrolling Channel Index allows you to view and select from all receivable channels scrolling on the screen without leaving the current channel.

Scrolling Channel Index will not function when Parental Lock is activated.

To use the Scrolling Channel Index function


1 Press 🕕 .

The current channel will be reduced in size and displayed on the left in normal motion picture format. The first channel is briefly displayed on the bottom-right side of the screen, then frozen. It scrolls up and the next channel appears on the bottom-right, and the process is repeated with the other channels.




2 Move the joystick up and down so that the channel you wish to view is displayed in the cyan frame, and press 🕀.

To return to scrolling, move the joystick up and down again.



3 To enlarge the selected channel into the left frame, press again. The selected channel will be displayed in normal motion picture, and the sound also switches to this channel.



To change the direction of scrolling, move the joystick up or down once.

To increase scrolling speed, hold the joystick up or down.

4 Press .

The selected channel will be enlarged for normal viewing.



To cancel Scrolling Channel Index

Press again to resume normal viewing.

- Sound will only be heard from the center picture.
- If one of the pictures received through Scrolling Channel Index is snowy, the entire screen may become unstable. In this case, skip the snowy channel. (see "Channel Skip/Add" on page 57)
- If you leave the Scrolling Channel Index screen displayed for an hour without any additional operation, Scrolling Channel Index is canceled and the normal picture reappears.
- Index cannot be used in combination with set-top boxes, DBS receivers, or cable boxes.
- Scrolling Index feature does not function if you use a cable box to view all channels.

Using Wide Mode

Wide Screen mode lets you watch 4:3 normal broadcasts in several Wide Screen modes (16:9 aspect ratio).

You can also access the Wide Mode settings in the Screen menu. For details, see page 58.

- When viewing high-definition programs broadcast in 720p/1080i, it is not possible to change between Wide Screen modes.
- Press WIDE MODE repeatedly to toggle through the following Wide Mode settings.

Example

Description



Wide Zoom enlarges the center portion of the 4:3 picture proportionately; however, only the left and right edges of the screen are stretched to fill the 16:9 screen. The picture has a normal appearance, as much as possible.



Wide Zoom

ŧ




Normal returns the 4:3 picture to its original size. Bars are visible at left and right sides to fill the 16:9 screen.



Norma

ŧ





Full

+



Zoom


Zoom Mode enlarges the entire 4:3 picture proportionately to fill the 16:9 screen. Useful for watching Letterbox movies.



When you change channels or inputs, the Wide Mode settings revert to the 4:3 Default setting in the Screen menu. To retain the current Wide Mode setting as channels and inputs are changed, set 4:3 Default to Off. For details, see page 58.

Using the Menus

Overview



Opening and choosing a menu:

- 1 Press MENU to display the menu screen.
- 2 Move the joystick to the desired menu icon and press 🕞 to select it.
- **3** Use the joystick to scroll through the features.
- 4 See the specific menu page for instructions on moving through the menu.

The menu gives you access to the following features:

Menu Icon	Description	Page
Video	Allows you to make adjustments to your picture settings. It also allows you to customize the Picture Mode based on the type of program you are viewing.	52
Audio	Offers enhanced audio options such as listening to second audio programming (SAP), or customizing the Effect of the sound on your projection TV.	54
Channel	Allows you to set up a Favorite Channel list, run the Auto Program function, and more.	56
Wide	Allows you to set the wide screen mode, adjust the vertical center in wide mode, and set the 4:3 Default mode.	58
Timer	Lets you set the clock on your projection TV and allows you to program your projection TV for scheduled viewing using the Timers.	60
Setup	Provides several options for setting up your channels, labeling your Video inputs, and selecting the language of the on-screen menus.	61

To end a menu session:

Press MENU again.

To end one menu session and move to another:

Press the joystick to return to the menu icons.

Move the joystick or to choose the next menu icon and press ⊕ to select it.



Using the Video Menu

To select the Video Menu

- Press MENU.
- Move the joystick to the Video icon and press .
- 3 Use the joystick to scroll through the features.
- 4 Press 🕁 to select a feature. That feature's adjustment appears.



- 5 Use the joystick to make the desired adjustments.
- 6 Press 🕀 to select/set.
- **7** Press MENU to exit the menu screen.

To restore the factory default settings for Picture, Brightness, Color, Hue, Sharpness and Color Temp

☐ Press RESET on the remote control when in the Video menu.

Selecting Video Options

To quickly and easily change from one Video Mode to another, use the PIC MODE on the remote control.

The Video menu includes the following options.

Option	Description	
Mode Customized	Vivid	Select for enhanced picture contrast and sharpness.
picture	Standard	Recommended for Normal viewing conditions.
viewing	Movie	Select for soft, film like, picture.
	Pro	Select for professional monitor like appearance.
		lter the Video menu settings (Picture, Brightness, .) for each Mode.
Picture	Adjust to increase picture contrast and deepen the color or decrease picture contrast and soften the color.	
Brightness	Adjust to brighten or darken the picture.	
Color	Adjust to increase or decrease color intensity.	
Hue	Adjust to increase or decrease the green tones.	
Sharpness	Adjust to sharpen or soften the picture.	
Color Temp	Choose from t	hree color temperatures:
White intensity adjustment	Cool	Select to give the white colors a blue tint.
	Neutral	Select to give the white colors a neutral tint.
	Warm	Select to give the white colors a red tint (NTSC-Standard).

Option	Description	
DRC Mode Digital Reality	C	resolution picture with 4x density, for high quality VD player, Satellite receiver).
	Interlaced	Recommended for moving pictures.
Creation	Progressive	Recommended for still images and text.
	CineMotion	Recommended for 24 frame-per-second films.

Using the Menus



Using the Audio Menu

To select the Audio Menu

- 1 Press MENU.
- Move the joystick to the Audio icon and press .
- 3 Use the joystick to scroll through the options.
- 4 Press (+) to select an option. That option's settings appear.
- 5 Use the joystick to scroll through the settings.
- Press to select the desired setting.
- 7 Press MENU to exit the menu screen.

To restore the factory default settings for Treble, Bass and Balance

☐ Press RESET on the remote control when in the Audio menu.

Selecting Audio Options

The Audio menu includes the following options:

Option	Description	
Treble	Adjust to increase or decrease higher-pitched sounds.	
Bass	Adjust to increa	ase or decrease lower-pitched sounds.
Balance	Adjust to emph	asize left or right speaker balance.
Steady Sound	On	Select to stabilize the volume.
	Off	Select to turn off Steady Sound.
Effect	TruSurround	Select for surround sound (for stereo programs only).
	Simulated	Adds a surround-like effect to mono programs.
	Off	Normal stereo or mono reception.
MTS Enjoy stereo,	Stereo	Select for stereo reception when viewing a program broadcast in stereo.
bilingual and mono programs	Auto-SAP	Select to automatically switch the projection TV to second audio programs when a signal is received. (If no SAP signal is present, the projection TV remains in Stereo mode.)
	Mono	Select for mono reception. (Use to reduce noise during weak stereo broadcasts.)

Option	Description	
Speaker	On	Select to turn on the projection TV speakers.
	Off	Select to turn off the projection TV speakers and listen to the projection TV's sound only through your external audio system speakers.
Audio Out Easy control of volume adjustments	Variable	The projection TV's speakers are turned off, but the volume output from your audio system can still be controlled by the projection TV's remote control.
	Fixed	The projection TV's speakers are turned off and the volume, bass and treble output of the projection TV is fixed. Use your audio receiver's volume control to adjust the volume through your audio system.


Using the Menus



Using the Channel Menu

To select the Channel Menu

- 1 Press MENU.
- Move the joystick to the Channel icon and press.
- 3 Use the joystick to scroll through the features.
- 4 Press 🕁 to select a feature.
 That feature's options appear.
- 5 Use the joystick to scroll through the options.
- 6 Press 🕀 to select the desired option.
- **7** Press MENU to exit the menu screen.



The Channel menu includes the following options:

Option	Description	
Favorite Channel	Auto	Select if you want Favorite Channel options to be set automatically to the last eight channels selected with the 0-9 buttons.
	Manual	Select if you want to input your own selections as Favorite Channel options.
		Press to select a favorite channel number.
		2 Use the joystick to scroll through the channels until you find the channel you want to add to your favorites.
		3 Press 🕀 to select it.
Cable	On	Select if you are receiving cable channels with a CATV cable.
	Off	Select if you are using an antenna.
	You should setting.	d run Auto Program after changing the Cable




Option	Description	
Channel Fix Useful when you have a cable box or satellite receiver connected	2-6	"Fix" your projection TV's channel setting to 3 or 4 and use the cable box, VCR or satellite receiver to change channels. Select one of these settings if you have connected the device to the VHF/UHF jack.
	AUX 2-6	Same as 2-6, except you select one of these settings if you have connected the device to the AUX jack. (see page 15)
	Video 1	Use when connecting a cable box to control external video sources. TV output should be connected through the cable box.
Auto Program	Automatically programs the projection TV for all receivable channels.	
Channel Skip/Add	 Removes and adds viewable channels. Use the joystick to scroll through the channels until you find the channel you want to skip/add. Press to select it. Press the joystick up or down to toggle between "Add" and "Skip." Press to select. 	
Channel Label		channels with their station call letters.



Using the Wide Menu

To select the Wide menu

- 1 Press MENU.
- 2 Use the joystick to move to the Wide icon and press .
- Move the joystick to scroll through the features.
- 4 Press to select a feature.
 That feature's options appear.
- 5 Use the joystick to scroll through the options.
- 6 Press 🕀 to select the desired option.
- 7 Press MENU to exit the menu screen.



Selecting Wide Options

To change from one Wide Mode to another, use the WIDE MODE button on the remote control.

Wide Mode is unavailable while in Twin View, Index or Freeze mode.

The 4:3 Default functions only when the projection TV receives 480i signals.

The Wide menu includes the following options:

Option	Description	
Wide Mode Select a Wide Mode to use for	Wide Zoom	Select to enlarge the 4:3 picture, while the upper and lower parts of the picture are condensed to fit the wide screen.
4:3 sources.	Normal	Select to return the 4:3 picture to normal mode.
	Full	Select to enlarge the 4:3 picture horizontally only, to fill the wide screen.
	Zoom	Select to enlarge the 4:3 picture horizontally and vertically to an equal aspect ratio that fills the wide screen.
4:3 Default Select the default Screen Mode to use for 4:3 sources.	Wide Zoom	Select to enlarge the 4:3 picture, while the upper and lower parts of the picture are condensed to fit the wide screen.
	Normal	Select to return the 4:3 picture to normal mode.
	Full	Select to enlarge the 4:3 picture horizontally only, to fill the wide screen.
	Zoom	Select to enlarge the 4:3 picture horizontally and vertically to an equal aspect ratio that fills the wide screen.
	Off	Select to continue using the current Wide Mode setting when the channel or input is changed.

If 4:3 Default is set to anything but Off, the Wide Mode setting changes only for the current channel. When you change channels (or inputs), Wide Mode is automatically replaced with the 4:3 Default setting. To retain the current Wide Mode setting as channels and inputs are changed, set 4:3 Default to Off.

Option	Description	
Vertical Center	Allows you to move the position of the picture up and dow the window. (Available only in Wide Zoom and Zoom mo	
	Move the joystick up or down to choose a position and press .	

Some wide-screen programs (particularly certain theatrical releases) will be shown in aspect ratios that require the display of black bands at the top and bottom of your 16:9 screen. For more details, check the documentation that came with your DVD, or contact your content provider.



Using the Timer Menu

To select the Timer menu

- Press MENU.
- Move the joystick to the Timer icon and press (-).

To set the Current Time

1 Use the joystick to select "Current Time", then press



- 2 If it is currently Daylight Saving Time, be sure to set the mode to "On" first.
- 3 Use the joystick to enter the correct time, then press (-).
- 4 Press MENU to exit the menu screen.

To set the Timer

Before setting the timer, be sure to set your projection TV's clock to the current time and Daylight Saving Mode.

- 1 Move the joystick to "Timer 1" or "Timer 2", then press (4).
- 2 Use the joystick to enter your day, time, channel, and timer duration preferences; then, press (+) to select each one.
- 3 Press MENU to exit the menu screen.

To reset the Clock or Timers

Press RESET on the remote control after selecting that option in the Timer menu.

Selecting Timer Options

The Timer menu includes the following options:

ogram	Select to set the Timer by day, time, duration,
	and channel.
f	Select to turn off the Timer. (Your previous settings will be saved.)
Set the current time.	
1	Select in the Spring to adjust the time during Daylight Saving Time.
f	Select in the Fall to adjust the time at the end of Daylight Saving Time.
	t the current to

Parental Control Caption Vision:CC1 Video Label Language:English

Move: ↑↓→← Select: ⊕ End:



Using the Setup Menu

To select the Setup Menu

- Press MENU.
- Move the joystick to the Setup icon and press .
- 3 Use the joystick to scroll through the features.
- 4 Press 🕀 to select a feature.
 That feature's options appear.
- 5 Use the joystick to scroll through the options.
- 6 Press 🕀 to select the desired option.
- 7 Press MENU to exit the menu screen.



The Setup menu includes the following options:

Option	Description	
Parental Control	Allows you to set up the TV to block programs according to their content and rating levels. For details about setting, see "Using the Parent Menu" on page 63.	
Caption Vision	Allows you to select from three closed caption modes (for programs that are broadcast with closed captioning).	
	Off	Turns off Caption Vision.
	CC1, CC2, CC3, CC4	Displays a printed version of the dialog or sound effects of a program. (Should be set to CC1 for most programs.)
	Text1, Text2, Text3, Text4	Displays network/station information presented using either half or the whole screen (if available). For closed captioning, set to CC1.
	XDS (Extended Data Service)	Displays a network name, program name, program length, and time of the show if the broadcaster offers this service.

(Continued)

Using the Menus

Option	Description	Description	
Video Label	Allows you to label the audio/video components you connected to the projection TV so you can identify them when using TV/VIDEO. When in the Setup menu's Video Label feature, use the joystick to highlight an input to label, then press to select it. Use the joystick to scroll through the labels. Press to select the component you connected to each of the input jacks on the back of your projection TV. Select "Skip" if you do not have a component connected to a particular set of input jacks.		
	VIDEO 1	Receiver, VHS, DVD, Satellite, Cable Box, 8 mm, DTV, LD, Beta, Skip	
	VIDEO 2/3/4	VHS, DVD, Satellite, Cable Box, 8 mm, DTV, LD, Beta, Skip	
	VIDEO 5/6/7	DVD, Satellite, Cable Box, DTV, HD, Skip	
	If you select "Skip", your projection TV skips this connection when you press TV/VIDEO.		
	When you have set the Video Label for Video 1 to "Receiver", you are able to change channels with the remote, and the TV input will stay on Video 1. Refer to "Connecting an AV Receiver" on page 30 for more details.		
Language	Select to display all on-screen menus in your language of choice: English, Español, Français.		

Using the Parent Menu

The Parent menu allows you to set up the TV to block programs according to their content and rating levels.

These ratings are assigned by a federal rating board. Not all programs are rated. Using the Parental Lock blocks programs with a specific rating, but it does not block an entire channel.

Scrolling Channel Index will not function when Parental Lock is activated.

To select the rating

First, set a password, then select the country you reside in (U.S.A. or Canada) and your desired rating.

- 1 Press MENU.
- 2 Move the joystick to the Setup icon and press .



3 Make sure that "Parental Control" is selected, and press 🕀.



- 4 Use the 0-9 buttons on the remote control to enter your four-digit password.
- 5 Confirm your password by entering it again. Your password is stored and the Parent menu options appear.
 - You need the password entered here for any future access into the Parent menu. If you lose your password, see "Lost password" on page 77.
 - If you want to change the password, see page 65.

Using the Menus

6 Make sure that "Country" is selected, and press ①.



Move the joystick up or down to select U.S.A. or Canada according to the country you reside in, and press 🔂.



8 Move the joystick down to select "Parental Lock", and press 🕀.



9 Move the joystick up or down to select a desired rating, and press 🕁.

If you select Child, Youth, Young Adult or Custom, the Parental Control is activated automatically.



If you want to select the ratings from Custom, see "Using Custom Rating Options" on page 66.

10 Press MENU to exit the menu screen.

if you are not familiar with the Parental Guideline rating system, you should select Child, Youth, or Young Adult to help simplify the rating selection. To set more restrictive ratings, select Custom.

For descriptions of Child, Youth, and Young Adult ratings, see pages 69 and 70. The Parent menu includes the following options.

Option	Description	
Parental Lock Turn ratings on/	Off	Parental lock is off. No programs are blocked from viewing.
off and select a rating system	Child	Maximum ratings permitted are: US: TV-Y, TV-G, G Canada: TV-Y, C, G
Youth		Maximum ratings permitted are: US: TV-PG, PG Canada: TV-PG, PG, 8 ans+
	Young Adult	Maximum ratings permitted are: US: TV-14, PG-13 Canada: TV-14, 14+, 13 ans+
	Custom	Select to set ratings manually. US: See page 69 for details. Canada: See page 70 for details.
Change Password	For changing y	our password. (see below)

To deactivate the Parental Control feature

Set Parental Lock to Off when in the Parent menu.

To change the password

- 1 Select Change Password option when in the Parent menu using the joystick, and press (+).
- 2 Enter a new four-digit password using the 0-9 buttons.
- **3** Confirm the new password by entering it again.
- 4 Press MENU to exit the menu screen.

Viewing Blocked Programs


You can view a blocked program by entering the password.

- 1 Press ENTER when tuned to a blocked program.
- 2 Enter your password using the 0-9 buttons.
 Parental Control will be canceled temporarily until you turn your projection TV off.


Using Custom Rating Options

If you want to select the ratings to be blocked from Custom, follow the procedure below.

- Perform the steps 1 to 8 in "To select the rating" on page 63 to display the Parental Lock options.
- Move the joystick up or down to select "Custom," and press (+).




3 Make sure that "Movie Ratings" is selected, and press 🕀.



4 Move the joystick up or down to select the rating to be blocked, and press 🕀.

The findicator automatically appears beside the selected rating and all "higher" ratings, indicating that the programs that match the ratings will be blocked.




To unblock a rating, select it by moving the joystick up or down, then press ⊕ The indicator ⊕ changes into "-" and all "lower" ratings are unblocked.

Move the joystick left, then down, to select "TV Rating" or "Program," and press (+).




6 The "TV Rating" setting menu appears.



Move the joystick up or down to select the rating to be blocked, and press +.

The indicator automatically appears beside the selected rating and all "higher" ratings, indicating that the programs that match the ratings will be blocked.




To unblock a rating, select it by moving the joystick up or down, then press ①. The indicator ② changes into "-" and all "lower" ratings are unblocked.

Some TV ratings have additional content ratings called "extenders." The extenders are defined as follows: D (sexually suggestive Dialog), FV (Fantasy Violence), L (Coarse Language), S (Sexual situations) and V (Violence). By setting the extenders, you can define additional viewing limits. All of the extenders included in the selected ratings will be blocked. If you wish to allow any of them to be viewed, go to step 8.

Using the Menus

8 Move the joystick left or right to select the extender to be viewed, and press 🕁.



"-" appears beside the selected extender, indicating that the programs that match the extender can be viewed.

If you press ⊕ again, ♠ is displayed to show that the programs that match the extender will be blocked again.

9 Repeat step 8 for other extenders.

All programs that match the ratings you select and higher, except for the extenders that were canceled, will be blocked.

10 Press MENU to exit the menu screen.

US custom rating options

If you selected U.S.A. as the country of residence on page 63, the Custom Rating Menu includes the following options. (If you selected Canada, see page 70.)

Option	Description		
Movie Rating	G	All children and General Audience.	
	PG	Parental Guidance suggested.	
	PG-13	Parental Guidance for children under 13.	
	R	Restricted viewing, parental guidance is suggested for children under 17.	
	NC-17 and X	No one 17 and under allowed.	
TV Rating	Age-Bas	ed Options	
$Block\ programs$	TV-Y	All children.	
by their rating,	TV-Y7	Directed to older children.	
content or both	TV-G	General Audience.	
	TV-PG	Parental Guidance suggested.	
	TV-14	Parents Strongly cautioned.	
	TV-MA	Mature Audience only.	
	Content-Based Options		
	FV	Fantasy Violence.	
	D	Suggestive Dialogue.	
	L	Strong Language.	
	S	Sexual situations.	
	V	Violence.	
Unrated	Block	Blocks all programs and movies that are broadcast	
$Block\ programs$		without a rating.	
or movies that	Allow	Allows programs and movies that are broadcast	
are broadcast		without a rating.	
without a rating			

The content ratings will increase depending on the level of the age-based rating. For example, a program with a TV-PG V (Violence) rating may contain moderate violence, while a TV-14 V (Violence) rating may contain more intense violence.

To ensure maximum
blocking capability, the
age-based ratings should
be blocked.

If you choose to block unrated TV programs, please be aware that the following programs may be blocked: emergency broadcasts, political programs, sports, news, public service announcements, religious programs and weather.

Using the Menus

Canadian custom rating options

If you selected Canada as the country of residence on page 63, the Custom Rating Menu includes the following options. (If you selected U.S.A., see page 69.)

Option	Description	
English Rating	С	All children.
	C8+	Children 8 years and older.
	G	General programming.
	PG	Parental Guidance.
	14+	Viewers 14 and older.
	18+	Adult programming.
French Rating	G	General programming.
	8 ans+	Not recommended for young children.
	13 ans+	Not recommended for ages under 13.
	16 ans+	Not recommended for ages under 16.
	18 ans+	Programming restricted to adults.
USA Rating	See "TV Rating" on page 69 for details.	

Other Information

Programming the Remote Control


The remote control is preset to operate Sony brand video equipment.

Sony Equipment	Switch Position on Remote Control	Programmable Code Number
Beta, ED Beta VCRs	AV1	303
8 mm VCR	AV2	302
VHS VCR	AV3	301
DVD Player	DVD	751

If you have video equipment other than Sony brand that you want to control with the projection TV's remote control, use the following procedures to program the remote control.




The equipment must have infrared (IR) remote capability in order to be used with the remote control.




From the "Manufacturer's Codes" listed on page 73, select the three-digit code number for the manufacturer's code for your component. If more than one code number is listed, start with the number listed first. Use the code number to complete the following procedure.


To program a cable box or a satellite receiver


- Open the panel of the remote control.
- Press CODE SET inside the panel.
- Close the panel and press SAT/CABLE (FUNCTON).
- Enter the three-digit manufacturer's code number using the 0-9 buttons.
- Press ENTER.





Other Information





To program video equipment

- 1 Open the panel of the remote control.
- 2 Move the slide switch to the desired component type.
- 3 Press CODE SET inside the panel.
 - You must perform step 4 within 10 seconds of step 3, or you must start again from step 3.
- 4 Close the panel and enter the three-digit manufacturer's code number using the 0-9 buttons.
- 5 Press ENTER.
- To check if the code number works, aim the projection TV's remote control at the component, open the panel, and press the green POWER button. If it responds, the programming is completed. If not, try using the other codes listed for that manufacturer.

Tips

- If more than one code number is listed, try entering them one by one until you come to the correct code for your component.
- ☐ If you enter a new code number, the code number you previously entered at that setting is erased.
- In some rare cases, you may not be able to operate your component with the Sony remote control. In this case, use the component's own remote control unit.

Manufacturer's Codes

VCRs

VOITS	
Manufacturer	Code
Sony	301
Admiral	327
(M. Ward)	
Aiwa	338, 344
Audio Dynamic	314, 337
Broksonic	319, 317
Canon	309, 308
Citizen	332
Craig	302, 332
Criterion	315
Curtis Mathes	304, 338, 309
Daewoo	341, 312, 309
DBX	314, 336, 337
Dimensia	304
Emerson	319, 320, 316,
	317, 318, 341
Fisher	330, 335
Funai	338
General Electric	329, 304, 309
Go Video	322, 339, 340
Goldstar	332
Hitachi	306, 304, 305,
	338
Instant Replay	309, 308
JC Penney	309, 305, 304,
	330, 314, 336, 337
JVC	314, 336, 337,
JVC	345, 346, 347
Kenwood	314, 336, 332,
	337
LXI (Sears)	332, 305, 330,
	335, 338
Magnavox	308, 309, 310
Marantz	314, 336, 337
Marta	332
Memorex	309, 335

	0.1
Manufacturer	Code
Minolta	305, 304
Mitsubishi/	323, 324, 325,
MGA	326
Multitech	325, 338, 321
NEC	314, 336, 337
Olympic	309, 308
Optimus	327
Panasonic	308, 309, 306, 307
Pentax	305, 304
Philco	308, 309
Philips	308, 309, 310
Pioneer	308
Quasar	308, 309, 306
RCA/	304, 305, 308,
PROSCAN	309, 311, 312,
	313, 310, 329
Realistic	309, 330, 328,
	335, 324, 338
Sansui	314
Samsung	322, 313, 321
Sanyo	330, 335
Scott	312, 313, 321,
	335, 323, 324,
<u></u>	325, 326
Sharp	327, 328
Shintom	315
Signature 2000 (M. Ward)	338, 327
SV2000	338
Sylvania	308, 309, 338,
	310
Symphonic	338
Tashiro	332
Tatung	314, 336, 337
Teac	314, 336, 338,
	337
Technics	309, 308
Toshiba	312, 311

Manufacturer	Code
Wards	327, 328, 335, 331, 332
Yamaha	314, 330, 336, 337
Zenith	331

DVD Players

Manufacturer	Code
Sony	751
Panasonic	753
Pioneer	752
RCA	755
Toshiba	754

Cable Boxes

Manufacturer	Code
Hamlin/Regal	222, 223, 224,
	225, 226
Jerrold/G.I./	201, 202, 203,
Motorola	204, 205, 206,
	207, 208, 218
Oak	227, 228, 229
Panasonic	219, 220, 221
Pioneer	214, 215
Scientific	209, 210, 211
Atlanta	
Tocom	216, 217
Zenith	212, 213

Satellite Receivers

Manufacturer	Code		
Sony	801		
General	802		
Electric			
Hitachi	805		
Hughes	804		
Panasonic	803		
RCA/	802, 808		
PROSCAN			
Toshiba	806, 807		

Operating Other Components with Your Projection TV Remote Control

Operating a VCR

Open the panel and move the slide switch to the AV input you coded for this device.

To Do This	Press
Turn on/off	green POWER button (inside the panel)
Change channels	CH +/-
Record	→ and REC simultaneously
Play	>
Stop	
Fast forward	>>
Rewind the tape	←
Pause	II (press again to resume normal playback)
Search the picture	▶▶ or ◀◀ during playback
forward or backward	(release to resume normal playback)
Change input mode	Slide switch

Operating a DVD Player

Open the panel and move the slide switch to the DVD input you coded for this device.

To Do This	Press
Turn on/off	green POWER button (inside the panel)
Play	>
Stop	
Pause	■ (press again to resume normal playback)
Step through different tracks of an audio disc	▶► to step forward or ◀◀ to step backward
Step through different chapters of a video disc	CH+ to step forward or CH- to step backward
Display the DVD menu	DVD MENU
Display the menu (Setup)	MENU
Operate the DVD menu	1 , ↓ , ← , → , ENTER

Operating a Cable Box

To Do This	Press
Turn on/off	SAT/CABLE (POWER)
Select Cable Box	SAT/CABLE (FUNCTION)
Select a channel	0-9 buttons, ENTER
Change channels	CH +/-
Back to previous channel	JUMP

Operating a Satellite Receiver

To Do This	Press
Turn on/off	SAT/CABLE (POWER)
Select Satellite Receiver	SAT/CABLE (FUNCTION)
Select a channel	0-9 buttons, ENTER
Change channels	CH +/-
Back to previous channel	JUMP
Display channel number	DISPLAY
Display DBS guide	GUIDE
Display DBS menu	MENU
Move highlight (cursor)	Joystick or arrows
Select item	(-)

Troubleshooting

If, after reading these operating instructions, you have additional questions related to the use of your Sony television, please call our Customer Information Services Center at 1-800-222-SONY (7669) (U.S. residents only) or (416) 499-SONY (7669) (Canadian residents only).

Problem	Possible Remedies
No picture	☐ Make sure the projection TV's power cord is connected securely to the wall outle
(screen not lit),	Push the power button on the front of the projection TV.
no sound	Check to see if the TV/VIDEO setting is correct: when watching TV, set to TV, and when watching connected equipment, set to VIDEO 1, 2, 3, 4, 5, 6 or 7.
	Try another channel. It could be station trouble.
	The Parental Control feature is activated (see "Using the Parent Menu" on page 63).
	☐ If your projection TV does not turn on, and a red light keeps flashing, your
	projection TV may need service. Call your local Sony Service Center.
Remote control	Batteries could be weak. Replace the batteries.
does not operate	Press TV (FUNCTION) when operating your projection TV.
	Make sure the projection TV's power cord is connected securely to the wall outle
	Locate the projection TV at least 3-4 feet away from fluorescent lights.
	Check the orientation of the batteries.
Dark, poor or no	Adjust the Picture setting in the Video menu (see page 52).
picture (screen lit),	Adjust the Brightness setting in the Video menu (see page 52).
good sound	☐ Check antenna/cable connections.
	Adjust the convergence again using FLASH FOCUS (see "Adjusting the
	Convergence Automatically – FLASH FOCUS TM –" on page 33).
Good picture,	Press MUTING so that "MUTING" disappears from the screen (see page 37).
no sound	☐ Make sure Speaker is set to On in the Audio menu (see page 55).
	☐ Check the MTS setting in the Audio menu (see "MTS" on page 54).
Cannot receive digital channels (when a DTV receiver is	☐ Check the connections between the DTV receiver and the projection TV (see pag 28).
connected)	Check your local listings to find out if you can receive digital broadcasts in your
connected)	area.
Cannot receive upper channels	Change Cable to Off (see page 56).
(UHF) when	Use Auto Program in the Channel menu to add receivable channels that are not
using an antenna	presently in TV memory (see page 57).
No color	Adjust the Color settings in the Video menu (see page 52).
Only snow and noise	Check the Cable setting in the Channel menu (see "Cable" on page 56).
appear on the screen	☐ Check the antenna/cable connections.
	☐ Make sure the channel is broadcasting programs.
	Press ANT to change the input mode (see page 40).
Dotted lines	Adjust the antenna.
or stripes	Move the projection TV away from noise sources such as cars, neon signs, or hai
_	dryers.

Problem	Pos	ssible Remedies
Projection TV is fixed to one channel	<u> </u>	Use Auto Program in the Channel menu to add receivable channels that are not presently in TV memory (see page 57). Check your Channel Fix settings (see page 57).
Double images or ghosts		Use a highly directional outdoor antenna or a cable (when the problem is caused by reflections from nearby mountains or tall buildings).
Cannot operate menu		If the item you want to choose appears in gray, you cannot select it. Turn the projection TV's power off and on again.
Cannot receive any channels when using cable TV	0	Use Auto Program in the Channel menu to add receivable channels that are not presently in TV memory (see page 57). Check your cable settings. Make sure Cable is set to On in the Channel menu (see page 56).
Cannot gain enough volume when using a cable box		Increase the volume of the cable box using the cable box's remote control. Then press TV (FUNCTION) and adjust the projection TV's volume.
The TV does not display all available cable channels		Make sure Cable is set to On in the Channel menu (see "Cable" on page 56). Use Auto Program in the Channel menu to add receivable TV channels that are not presently in TV memory (see page 57).
Cannot receive channels Unable to select a channel		Use Auto Program in the Channel menu to add receivable TV channels that are not presently in TV memory (see page 57).
Lost password		In the password screen (see page 63), enter the following master password: 4357. The master password clears your previous password; it cannot be used to temporarily unblock channels.
Cannot change channels with the remote control	0	Be sure you have not inadvertently switched your projection TV from channel 3 or 4 setting if you are using another device to change channels. If you are using another device to control channels, be sure the "function" button for that device has been pressed, or the slide switch is set correctly. For example, if you are using your cable to control channels, be sure to press SAT/CABLE.
Cannot cycle through the other video equipment connected to the projection TV		Be sure the Video Label feature has not been set to Skip (see page 62).
There is a black box on the screen		You have selected a text option in the Setup menu and no text is available. (see page 61 to reset Setup selections) To turn this feature off, select Off in the Caption Vision option. If you were trying to get closed captioning, select CC1 instead of Text 1-4.
There is no twin picture or it is just static	0 0 0	Be sure your twin picture is set to a video source/channel that has a program airing. You may be tuned to a video input with nothing connected to it. Try cycling through your video inputs using TV/VIDEO. Twin View is not set to receive a signal from the AUX input. If you have connected a VCR, DVD player or satellite receiver to the AUX input on the projection TV, it will not show in the second picture.

Other Information

Problem	Po	Possible Remedies	
You get the same program in the window picture as in the main picture		Both may be set to the same channel. Try changing channels in either the main picture or the window picture. You may be running all your channels through a cable box. The cable box will only unscramble one signal at a time, so you cannot use the Twin View feature. I possible, run a direct cable to your projection TV's VHF/UHF input (this will only work if your cable system provides an unscrambled signal.)	
You cannot get anything but TV channels in your second picture		Be sure the video label has not been set to skip your video inputs. See the Setup menu on page 62.	
Favorite Channel does not display your choices		Verify that Favorite Channel is set to Manual in the Channel menu (see "Favorite Channel" on page 56).	
Some video sources do not appear when you press TV/VIDEO		Ensure that Video Label is not set to SKIP (see "Video Label" on page 62).	
Digital cable box does not work	<u> </u>	Be sure that you have not connected the digital cable box to the TV's TO CONVERTER jack. This jack is not compatible with digital cable boxes. If you are connecting a VCR and digital cable box, you must use a special bidirectional splitter that is designed to work with your digital cable box. Contact your cable provider for details.	

Specifications

Projection System	3 picture tubes, 3 lense	s, horizontal in-line system	
Picture Tube		monochrome tubes (6.3 raster size), with optical	
	coupling and liquid cooling system		
Projection Lenses	High performance, larg		
	diameter hybrid lens F		
Antenna	75 ohm external termin		
Television System	NTSC, American TV Standard		
Screen Size (measured diagonally)	46 inches (116.84 cm)	(KP-46WT510)	
	51 inches (129.54 cm)	(KP-51WS510)	
	57 inches (144.78 cm)		
	65 inches (165 cm) (Kl	P-65WS510)	
Channel Coverage			
VHF	2-13		
UHF	14-69		
CATV	1-125		
Power Requirements	120V, 60 Hz		
Number of Inputs / Outputs			
DVI-HDTV		1 terminal, 3.3V T.M.D.S., 50 ohms	
		The DVI input terminal is compliant with the	
		EIA-861 standard and is not intended for use	
		with personal computers.	
Video (IN)	4	1 Vp-p, 75 ohms unbalanced, sync negative	
S Video (IN)	3	Y: 1 Vp-p, 75 ohms unbalanced, sync negative	
		C: 0.286 Vp-p (Burst signal), 75 ohms	
Audio (IN)	6	500 mVrms (100% modulation)	
		Impedance: 47 kiloohms	
AUDIO (VAR/FIX)	1	500 mVrms at the maximum volume setting	
- (, , , , , , , , , , , , , , , , , ,		(Variable)	
		500 mVrms (Fixed)	
		Impedance (output): 1 kiloohm	
TV Out	1	Video: 1 Vp-p 75 ohms unbalanced, Sync	
		negative	
		Audio: 500 mVrms (100% modulation)	
		Impedance (output): 1 kiloohm	
CONTROL S (IN/OUT)	1	minijacks	
Component Video Input	2 (Y, P _R , P _R)	Y: 1.0 Vp-p, 75 ohms unbalanced, sync	
	2 10	negative	
		P _B : 0.7 Vp-p, 75 ohms	
		P _R : 0.7 Vp-p, 75 ohms	
RF Inputs	2	K I I /	
Converter	1		
Speaker Output	20 W × 2		

(Continued)

Other Information

$42^{3}/4 \times 40 \times 24$ inches (1,086 × 1,017 × 609 mm) (KP-46WT510)
$47 \times 53^{1/8} \times 25^{5/8}$ inches $(1,194 \times 1,350 \times 650 \text{ mm})$ (KP-51WS510)
$52^{1}/4 \times 54^{1}/4 \times 27^{1}/4$ inches (1,326 × 1,377 × 690 mm) (KP-57WS510)
$60^{3}/4 \times 57^{3}/4 \times 29^{1}/2$ inches (1,542 × 1,466 × 750 mm) (KP-65WS510)
135 lb (61.3 kg) (KP-46WT510)
172 lb (78.2 kg) (KP-51WS510)
195 lb (88.6 kg) (KP-57WS510)
300 lb (136 kg) (KP-65WS510)
230 W
Under 1 W
RM-Y909
2 supplied for remote control
VMC-810/820/830 HG
RKC-515HG
RK-G69HG
VMC-10/30 HG
STR-V555ES or equivalent
SU-46WT5

Design and specifications are subject to change without notice.

Index	Contents of box 10 CONTROL S 31
Λ.	Convergence, adjusting automatically 33
Activating a Twin View screen 44	Convergence, adjusting manually 34
Adding channels to the channel list 57	D
Adjusting audio, Steady Sound 54	Doublight souting 60
ANT button 37	Daylight saving 60
Antenna, connecting 16	Digital Reality Creation 53
Audio menu 51 , 54	Digital TV connecting 28
Audio receiver, connecting 25	watching 42
Audio/Video cable 12	Digital TV program 42
Auto Program (channel setup) 32, 57	Digital TV program 42 Digital TV receiver, connecting 28
AV receiver, connecting to TV OUT 15, 30	DISPLAY button 37
•	Display, turning off 37
B	DRC (Digital Reality Creation) Mode, described 8
Balance, adjusting 54	DRC/ CINEMOTION button 38
Bass, adjusting 54	DVD MENU button 39
Batteries, inserting in remote 10	DVD player
Bilingual audio 54	using with TV remote control 74
Brightness, adjusting 52	with A/V connectors, connecting 27
C	with component video connectors, connecting 26
Cable	_
connecting 16–18	
setting On/Off 56	Effect
with VCR, connecting 19–20	Off 54
Cable box	Simulated 54
connecting with VCR 20	TruSurround 54
using with TV remote control 74	Enlarging pictures, in Twin View 46
Camcorder, connecting 29	Extended Data Service 61
Caption Vision 61	F
CATV. See cable.	Favorite Channel
Channel list, adding channels 57	auto 56
Channel menu 51 , 56	described 8
Channel Skip/Add 57	manual 56
Channels	setting up 56
Auto Program 57	using 43
creating labels 57	FAVORITES button 37
setting up 32	Features 8
CineMotion, DRC 38, 53	Flash Focus
Closed caption modes 61	described 9
CODE SET button 39	performing 33
Color temperature, adjusting 52	FREEZE button 37
Color, adjusting 52	Freeze, using 40, 47
Connecting Audio receiver 25	Front Panel Controls 13
AV receiver 30	FUNCTION buttons (WHITE) 38
Cable box 16–21	u .
Cable or antenna 16	Hookups 16–31
Camcorder 29	Hue, adjusting 52
Digital TV Receiver 28	riuo, aujusting ve
DVD player 26 , 27	
Satellite receiver 23, 24	Inputs, labeling 62
VCR 20–22 , 24	Installation of the projection TV 16–31
Connector Types 12	(Continued)
₹1	

J	Audio options 54
JUMP button 37	Timer options 60
Jump, using 40	Video options 52
The second secon	
Lahal	S S Widee cable 12
Label	S Video cable 12
channels 57	SAT/CABLE function button 38
video inputs 62	SAT/CABLE power button 38
M	Satellite receiver
MENU button 38	connecting 23
	using with TV remote control 75
Menus	Setting up channels 32 , 57
Audio 51, 54	Setup menu 51 , 61
Channel 51 , 56	Sharpness, adjusting 52
Setup 51 , 61	SLEEP button 37
Timer 51 , 60	Sleep, using 40
Video 51 , 52	Specifications 79–80
Wide 51 , 58	Steady Sound
MODE	adjusting 54
Movie 41 , 52	described 8
Pro 41 , 52	Surround sound 54
Standard 41 , 52	SYSTEM Off button 39
Vivid 41 , 52	STSTEM ON BUILDING
MTS/SAP button 41	T
MTS/SAP, using 54	Time
Muting, using 40	set current 60
ritating, asing 10	set daylight saving 60
P	Timer menu 51 , 60
Parental control, described 8	
Password, changing 65	Timer setting 60
PIC MODE button 37	Treble, adjusting 54
	Troubleshooting 76–78
Picture contrast, adjusting 52	TV function button 38
Picture size, adjusting in Twin View 46	TV power button 38
POWER button 39	TV/VIDEO button 38
POWER buttons (GREEN) 38	Twin View TM
Presetting channels 32 , 57	activating a picture 44
Problems, troubleshooting 76	described 8
D.	using 44
R	
Ratings	V
setting 63–68	VCR
viewing blocked programs 65	connecting two, for tape editing 22
Rear panel controls and connections 14 , 15	using with TV remote control 74
Remote control	with cable box, connecting 20
buttons inside panel 39	with cable, connecting 19
Function of buttons 40 , 41	with satellite receiver, connecting 24
inserting batteries 10	Video inputs, labeling 62
programming 71–73	Video menu 51 , 52
Remote control, operating other components with	Video Modes, selecting 52
Cable box 75	Viewing area, recommended 11
DVD player 74	VOL +/– button 37 , 40
Satellite receiver 75	TOD TI- DUMON OI, TO
VCR 74	Z
Removing channels from the channel list 57	Zoom feature, with Twin View 46
RESET button 37	Leadin reducte, with 1 with view 40
Resetting	
11000111115	

http://www.world.sony.com/

Sony Corporation Printed in U.S.A.